## 

## **Fitting Instructions** MRSA Resistant Full Length Mesh Bed Rai Protectors



- Raise bed to comfortable working height
- 2 Drop bed rails and remove mattress



5 Zip together full length of the bumper



3 Lay one bumper across the bed, ensuring mesh side is facing down



Raise the rail and place bumper over it, ensure the bottom half of the bumper is between the bed frame and the bed rail



- 6 Repeat for opposite side
- 7 Re-apply the mattress

www.mipuk.co.uk